




Instructions for disassembly and assembly

Disassembly of Ziacom® ratchets




Assembly of Ziacom® ratchets




Disassembling the adjustable torque wrench

Assembly/disassembly diagram (components may vary)



NOTE: the individual components come apart when the screw is removed. To assemble the torque wrench, simply assemble the individual parts in the same order and tighten the adjusting screw.

Disassembly of DSQ orthodontic implants insertion handle



Assembly of DSQ orthodontic implants insertion handle

